Installation and Assembly - Middle Rail Accessory

Models: **ACC670T, ACC670T-S, ACC680T, ACC680T-S, ACC670F, ACC670F-S, ACC680F, ACC680F-S**

IMPORTANT! Read instruction sheet before you start installation and assembly.
Before you start make sure all parts listed are included with your product.

Parts List

	Description	Qty.	ACC670T	ACC670T-S	ACC680T	ACC680T-S
A	center tilt bracket	1	201-1473	201-4473	201-1477	201-4477

	Description	Qty.	ACC670F	ACC670F-S	ACC680F	ACC680F-S
A	center flat bracket	1	200-0940	200-0941	200-0944	200-0945

Some parts may appear slightly different than illustrated.

A



TILT **FLAT**

1 Refer to **Step 2** of main product instruction sheet for installation of brackets. Center bracket (**A**) is to be installed between left and right adapter brackets as shown below. Screen attachment hardware is provided with main product.

NOTE: Middle rail accessory to be used in cases where screen has three rows of mounting inserts.

NOTE: Center tilt bracket does not need to be tensioned to hold screen angle. Refer to main product instructions on how to adjust tilt angle on left and right adapter brackets.



Note: "X" dimensions should be equal.

© 2007, Peerless Industries, Inc. All rights reserved.
All other brand and product names are trademarks or registered trademarks of their respective owners.